

SAR BACKCOUNTRY™ RAIL KIT

INSTALLATION INSTRUCTIONS

helmet accessories —



INNOVATE TO PROTECT



PURPOSE

For integration of accessory rails on the SAR Backcountry™ for mounting communication headsets, hearing protection, visor, lights, etc.

CONTENTS

- One (1) 1/8" Hex Key
- Two (2) Magpul® MOE® 5-Slot Picatinny Rails and Mounting Hardware
- Two (2) Team Wendy® SAR Accessory Rails (1 Left / 1 Right)
- Four (4) 10-32 x 1/4" Screws

INSTALLATION

STEP 1

Remove the two screws from each side of the SAR Backcountry™ using the included 1/8" hex key (figure 1).

STEP 2

Position the SAR Rail so that its two holes align with the respective mount holes in the helmet shell (figure 2).



FIG 1



FIG 2

STEP 3

Insert screws through the indicated mounting holes in the rail and tighten to the shell using the included 1/8" hex key (figure 3).



FIG 3

NOTE

The new screws provided in this kit are the same size as the original screws and are interchangeable. Set aside those that you don't use for safekeeping.

G431