

EXFIL[®] MARITIME LINER SYSTEM

INSTALLATION INSTRUCTIONS

aftermarket systems —



INNOVATE TO PROTECT



PURPOSE

The EXFIL® Maritime Liner System features sealed pads designed to withstand routine exposure to water. It utilizes Team Wendy's proven Zorbium® foam technology, offering leading-edge impact protection and maximum comfort. The liner system is available in two configurations compatible with either the EXFIL® Ballistic and EXFIL® Ballistic SL, or the EXFIL® Carbon and EXFIL® LTP.

CONTENTS

- > One (1) Rear Pad
- > One (1) Front Pad
- > One (1) Crown Pad, Configured for the EXFIL® Ballistic / SL or EXFIL® Carbon / LTP
- > One (1) EXFIL® Maritime Liner Fit Adjustment Pack with Four (4) Shim Pads

PERFORMANCE STANDARDS

Each EXFIL® helmet maintains its published performance standards and certifications when the EXFIL® Maritime Liner System is installed. See your respective helmet user guide for details.

INSTALLATION

STEP 1

Remove all pads from the helmet. Ensure the helmet shell interior is clean and dry.

STEP 2

Take the front pad of the maritime liner and fold the side flaps upward. Align the front of the pad with the front brim of the helmet. Press down firmly on the innermost section of the pad and work outward toward the helmet edge (figures 1A and 1B). Repeat for the crown pad followed by the rear pad (figures 2A and 2B). Ensure that the front and back liner edges are flush with the respective edge of the helmet.

NOTE

The center channel can be removed to accommodate overhead communication headbands.



EXFIL® BALLISTIC / SL

FIG 1A



EXFIL® CARBON / LTP

FIG 1B



EXFIL® BALLISTIC / SL

FIG 2A



EXFIL® CARBON / LTP

FIG 2B

STEP 3

For EXFIL® Carbon and EXFIL® LTP helmets, inspect the vent holes in the shell to ensure they are not covered.

FITTING

Before evaluating fit and comfort, allow the pads a few minutes to form to your head shape with the helmet's retention straps adjusted as usual. If fit feels too loose in any location, follow these instructions:

STEP 1

Remove the pad(s) you would like to fit closer to your head from the helmet. Select one foam shim pad from the fit adjustment pack.

STEP 2

Press the side of the shim pad with the VELCRO® hook onto the rear of the helmet pad (figure 3).

STEP 3

Press each helmet pad back into its original position within the helmet shell, with the shim pad between the shell and the helmet pad (figure 4).



FIG 3



FIG 4

STEP 4

Try on the helmet again and reevaluate fit and comfort after 30 seconds.

PAD CLEANING

Remove pad(s) from helmet and hand wash with mild soap. Allow pad(s) to air dry completely before reinstalling.

PAD REPLACEMENT

Periodically inspect the pads for damage or wear. Replace any pads with cuts, tears, soft spots or gross deformation.

6497