EXFIL® BALLISTIC RAIL 2.0 HELMET COVER

INSTALLATION INSTRUCTIONS





PURPOSE

Protects the helmet shell from wear and tear. Affords better cable management and allows the user to temporarily change the helmet shell color as desired.

CONTENTS

One (1) Helmet Cover

INSTALLATION

STEP 1

Center the cover around the shroud to ensure proper orientation (figure 1).



STEP 2

Pull the cover onto the helmet from front to back (figure 2) being careful to attach the hook on the interior of the helmet cover to the loop on the crown of the helmet. Ensure that the cover lies flat with minimal bunching.



FIG 2

STEP 3

Pull the cover down on each side of the helmet and adjust as needed to align the edge of the helmet cover with the top of the helmet rail.

STEP 4

For each loose loop tab on the corners of the helmet cover, identify where these tabs will fold over into the interior of the helmet (figure 3). Pull back the helmet pads to expose the hooks on the interior of the shell where the tabs will be placed. Fold the tabs and attach them to the hooks.



FIG 3

STEP 5

Press the helmet pads back into their original location.

G486

