# EXFIL® CARBON/LTP RAIL 2.0 HELMET COVER

INSTALLATION INSTRUCTIONS





# **PURPOSE**

Protects the helmet shell from wear and tear. Affords better cable management and allows the user to temporarily change the helmet shell color as desired.

### CONTENTS

- One (1) Helmet Cover
- Four (4) VELCRO® Hook Stickers

#### INSTALLATION

#### STEP 1

Center the cover around the shroud to ensure proper orientation (figure 1).





FIG 1 FIG 2

#### STEP 2

Pull the cover onto the helmet from front to back being careful to attach the hook on the interior of the helmet cover to the loop on the crown of the helmet. Ensure that the cover lies flat with minimal bunching.

## STEP 3

Unhook the lanyard on the rear of your helmet. Open the VELCRO® slot on the rear of the helmet cover and put the lanyard through it (figure 2).

#### STEP 4

Pull the cover down on each side of the helmet and adjust as needed to align the edge of the helmet cover with the top of the helmet rail. Reattach the lanyard to the bottom of your helmet.

### STEP 5

For each loose loop tab on the corners of the helmet cover, identify where these tabs will fold over into the interior of the helmet (figure 3). Place one of the four hook stickers on the interior of the helmet shell in each of those four locations.



FIG 3

#### STEP 6

Fold the tabs and attach them to the hook

# **■** NOTE

For the EXFIL® LTP (both sizes) and the EXFIL® Carbon size 1, the tabs on the rear of the helmet cover will fold to the side of the helmet shell. For the EXFIL® Carbon size 2, these tabs will fold along the rear of the helmet shell