

ESS PIVOT™ RAIL MOUNT

INSTALLATION INSTRUCTIONS



PURPOSE

The ESS Pivot™ Rail Mount allows for tool-free mounting of any Eye Safety Systems Pivot goggle – including the Profile Pivot™ and Influx Pivot™ – to the T-slots on the EXFIL® Rail 2.0 and EXFIL® Rail 3.0 systems.

CONTENTS

- Two (2) ESS Pivot™ Goggle Mounts
- Two (2) Weld Nuts
- Two (2) ESS Pivot™ Thumbscrews

INSTALLATION

STEP 1

Insert the thumbscrews through the goggle mounts. Loosely thread the weld nuts onto the thumbscrews (figure 1).

STEP 2

Slide a weld nut into the helmet rail T-slot (figures 2A and 2B). Position the goggle mount as desired, then tighten the thumbscrew by hand or by using a small coin in the thumbscrew slot. Repeat on opposite rail.

NOTE

Do not use hand tools to tighten the thumbscrew, as excessive force could result in damage to the thumbscrew.



FIG 1



FIG2A | EXFIL® Rail 3.0

STEP 3

Attach ESS Pivot™ goggles by securing the ends of the straps over the goggle mounts (figure 3).



FIG 2B | EXFIL® Rail 2.0



FIG 3

G447