



EXFIL[®] RAIL 2.0 ACCESSORY KIT

INSTALLATION INSTRUCTIONS

helmet accessories —



PURPOSE

Goggle posts serve as a bungee strap interface to provide more secure and consistent goggle placement than use of VELCRO® type hook and loop strapping. Fully compatible with Smith Optics ELITE® quick straps (Boogie Regulator, OTW and LOPRO). Two-slot mini-tinny (Picatinny) rails provide an alternate mounting point for lights and other small accessories.

CONTENTS

- Two (2) Mini-Tinny Rails
- Two (2) Washers Preinstalled on Two (2) 8-32 x 7/16" Screws to Attach the Goggle Posts
- Two (2) Goggle Posts
- Five (5) 4-40 x 3/8" Screws to Attach the Mini-Tinny Rails
- One (1) 1/16" Allen Key

INSTALLING THE GOGGLE POSTS

STEP 1

Remove the preinstalled washer from the 8-32 x 7/16"

screw. Place the 8-32 x 7/16" screw into the goggle post and connect with the washer. Repeat on the second set.

STEP 2

Slide the rear washer of the goggle post into the rear T-slot opening on the helmet and tighten firmly by hand (figure 1). Repeat on the other side.



FIG 1

INSTALLING THE MINI-TINNY RAILS

STEP 1

Use the 1/16" Allen key to remove the two existing screws from the front area of the helmet rail (figures 2A and 2B). Set them aside for safekeeping.



FIG 2A



FIG 2B

STEP 2

Fasten the mini-tinny using the 4-40 x 3/8" screws provided. Hand-tighten. Do not over torque to avoid stripping the screw head (figure 3). Repeat on other side if desired.




FIG 3

G388